

NCH-1000 Remote Override Installation Instructions

The following procedure explains how to install a remote override on an NCH-1000.

Step	Procedure
1	Use the rocker switch to power off the NCH-1000.
2	Remove the NCH-1000 from its panel.
3	Remove the six screws from the cover of the NCH-1000—do <i>not</i> remove the cover.
4	Turn the NCH over so that the cover is face down.
5	Remove the circuit board from the cover. <ul style="list-style-type: none">■ Stand-offs will remain in the cover.
6	Align the override board pins over the P3 jack on the NCH board and press gently to insert.
7	Remove the white stand-offs from the two posts on the cover, near the center on the end with the override board. <ul style="list-style-type: none">■ These stand-offs will not be re-used.
8	Insert the NCH board in the cover.
9	Re-insert and tighten the six screws in the cover to secure it.
10	Return the NCH to the panel.
11	Wire the appropriate override inputs.
12	Use the rocker switch to restore power to the NCH.
13	Replace panel covers.



THE CONTENTS OF THIS DOCUMENT ARE SUBJECT TO CHANGE WITHOUT NOTICE.

COPYRIGHT © 2006 BY NOVAR. ALL RIGHTS RESERVED.
PRINTED IN THE U.S.A.

NOVAR
6060 ROCKSIDE WOODS BLVD., CLEVELAND, OH 44131
Tel.: 800.348.1235 www.novar.com

This page intentionally left blank.